

Step 1

Paraffin Bath: Turn on the machine to maintain 126-134 deg F. (Allow a couple of hours for wax to melt) (grab treatment towel & plastic wrap)




Step 2

Treatment: Place treatment extremity into the wax and remove.



Step 3

Treatment: Repeat step 2 to allow up to 6 coats of wax.



Step 4

Treatment: After the 6th dip, place patient treatment extremity on top of the spread out plastic wrap.



Step 5

Treatment: Wrap wax covered extremity in the plastic wrap.



Step 6

Treatment: After wrapped in plastic snugly, Wrap the extremity in the treatment towel to hold heat. (Treatment is generally 15-20 mins)